


# 057 HS



# 057 HS

	Description	Part Number	Item Number		Description	Part Number	Item Number
1	Hood Assembly	057HS-1	600938	19	Vise Jaw Assembly (complete)	057HS-19	132819
2	8-32 x3/8 Hood Screws	057HS-2	174151	20	Fixed Jaw Insert (see below item BD0721XXXX)	057HS-20	see below
3	Z-Axis Locking Knob	057HS-3	132847	21	Mobile Jaw Insert (see below item BD0721XXXX)	057HS-21	see below
4	Brass Pellet	057HS-4	132848	22	Jaw Insert Screws	057HS-22	174192
5	Carriage Knob	057HS-5	131516	23	Rubber Bumper	057HS-23	129493
6	Z-Axis spring	057HS-6	132851	24	1/4-20 x 3/8 Socket Head Screw	057HS-24	174198
7	Jam Nut	057HS-7	132846	25	1/4-28 x 5/16 Set Screw	057HS-25	174061
8	Rod End Bearing	057HS-8	132849	26	Power Switch	057HS-26	132854
9	Joy Stick	057HS-9	132827	27	Tip Gage	057HS-27	BD0716XXXX
10	Motor Sub Assembly	057HS-10	502694	28	1/8" Hex Wrench	057HS-28	129109
11	Drive Belt	057HS-11	132850	29	Depth Calibration Gage Set	057HS-29	BD0720XXXX
12	Z-Axis Handle Knob	057HS-12	129600	30	Caution Label	057HS-30	131809
13	Z Guide Rod Cover	057HS-13	132833	31	Replacement Parts Label	057HS-31	132859
14	1/4-20 x 1/2 Socket Head Set Screw	057HS-14	174145				
15	Z-Axis Handle	057HS-15	132825				
16	F22 Cutter	057HS-16	BC0415XXXX				
17	Chip Shield	057HS-17	132364	20/21	057 HS Vise Jaw Surface Plate (Set)		BD0721XXXX
18	T22 Cutter Guide	057HS-18	BJ0562XXXX				